

Lewatit[®] MonoPlus M 500 is a strongly basic, gelular anion exchange resin with beads of uniform size (monodisperse) based on a styrene-divinylbenzene copolymer. The monodisperse beads are chemically and osmotically highly stable. The optimized kinetics lead to an increased operating capacity compared to ion exchange resins with heterodisperse bead size distribution.

Lewatit[®] MonoPlus M 500 is especially applicable for:

» the demineralization of water for industrial steam generation, e.g. Lewatit[®] WS System, Lewatit[®] Liftbed System or Lewatit[®] Rinsebed System

» polishing by a Lewatit[®] Multistep System in combination with

Lewatit[®] MonoPlus S 108 H.

Lewatit[®] MonoPlus M 500 is adding special features to the resin bed:

» high exchange flow rates during regeneration and loading

» good utilization of the total capacity

» a low demand for rinse water

» homogenous throughput of regenerants, water and solutions; therefore an homogeneous working zone

» nearly linear pressure drop gradient for the whole bed depth; therefore an operation with higher bed depth possible

The special properties of this product can only be fully utilized if the technology and process used correspond to the current state-of-the-art. Further advice in this matter can be obtained from Lanxess, Business Unit Liquid Purification Technologies.

PRODUCT INFORMATION

LEWATIT[®] MonoPlus M 500



Common Description

Delivery form	Cl-
Functional group	Quaternary ammonium
Matrix	Type 1
Structure	Styrenic
Appearance	Gel
	Yellow, translucent

Specified Data

Uniformity coefficient		max.	1.1
Mean bead size	d50	mm	0.62 (+/-0.05)
Total capacity (delivery form)		min. eq/L	1.3

This document contains important information and must be read in its entirety.

Typical Physical and Chemical Properties

Bulk density for shipment	(+/-	g/L	690
Density	5%)	approx. g/mL	1.08
Water retention (delivery form)		approx. weight %	48 - 55
Volume change (Cl- -OH-)		max. approx. %	24
Stability pH range			0-14
Storage time (after delivery)		max. years	2
Storage temperature range		°C	-20 - +40

Operation

Operating temperature		max. °C	70
Operating pH range	during exhaustion		0-12
Bed depth for single column		min. mm	800
Back wash bed expansion per m/h (20°C)		%	11
Specific pressure loss kPa*h/m2 (15°C)		kPa*h/m2 (15°C)	1
Max. pressure loss during operation		kPa	200
Specific flow rate		max. BV/h	60

Regeneration

NaOH regeneration	concentration	quantity	approx. wt. %	2-6
NaOH regeneration	co-current	quantity	min. g/L resin	80
NaOH regeneration	counter-current		min. g/L resin	50
Regeneration contact time			min. minutes	20
Slow rinse at regeneration flow rate			min. BV	2
Fast rinse at service flow rate			min. BV	2

This document contains important information and must be read in its entirety.

Additional Information & Regulations

Safety precautions

Strong oxidants, e.g. nitric acid, can cause violent reactions if they come into contact with ion exchange resins.

Toxicity

The safety data sheet must be observed. It contains additional data on product description, transport, storage, handling, safety and ecology.

Disposal

In the European Community Ion exchange resins have to be disposed, according to the European waste nomenclature which can be accessed on the internet-site of the European Union.

Storage

It is recommended to store ion exchange resins at temperatures above the freezing point of water under roof in dry conditions without exposure to direct sunlight. If resin should become frozen, it should not be mechanically handled and left to thaw out gradually at ambient temperature. It must be completely thawed before handling or use. No attempt should be made to accelerate the thawing process.

Packaging

The experience has shown that the packaging stability for reliable resin containment is limited to 24 months under the storage conditions described above. It is therefore recommended to use the product within this time frame; otherwise the packaging condition should be checked regularly.

This information and our technical advice – whether verbal, in writing or by way of trials – are given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. Our advice does not release you from the obligation to check its validity and to test our products as to their suitability for the intended processes and uses. The application, use and processing of our products and the products manufactured by you on the basis of our technical advice are beyond our control and, therefore, entirely your own responsibility. Our products are sold in accordance with the current version of our General Conditions of Sale and Delivery.

This document contains important information
and must be read in its entirety.